

F I G. 1

F I G. 2 ACTIVATE S10 NO RECORD MODE? S14 YES ИО **IMAGE CARD?** S16 YES NO MUSIC CARD? S22 YES KEY NO MUSIC? **INPUT** S24 YES KEY SELECT TUNE **INPUT** S26 **DETERMINE** KEY MIXING RATIO **INPUT** S18 **RELEASE** S28 RELEASE SHUTTER SHUTTER S30 S20 RECORD **IMAGE AND MUSIC RECORD** S12

WAITING FOR KEY INPUT

IMAGE AND AUDIO

NO RECORDING